

# Quick Start Guide



Model: ZL500

Version: 1.0

Due to regular upgrades of systems and products, ZKTeco could not guarantee exact consistency between the actual product and the written information in this manual.

## How to configure the lock to the **ZKBioHLMS** software?

### Step 1: Installing ZKBioHLMS

- ① Search for "ZKBioHLMS" on the ZKTeco's website <https://www.zkteco.com/en/> and download the installation package and install it.
- ② After installing and logging-in successfully, fill out the hotel information on the **Room Management** option of the Hotel module, including **Hotel Info Setting**, **Room Type**, **Room**, etc.

### Step 2: Configuring the SLG410 ZigBee gateway

Please refer the configuration processes in the **SLG410 QSG**.

### Step 3: Installing the Reader's driver

On the **Room View** page, click **Driver Download** to install the driver.

**Note:** The driver installation may be interrupted by the system. Please ignore the warning and continue with installation to issue the card. The driver is safe to use.

### Step 4: Issuing Default Net Card to connect the lock and gateway

- ① Open the **Hotel Info Setting** page, select **Default Net Card**, click **Default Net Card** to issue.
  - ② Open **Device Management**, choose the gateway which customers want to connect and then enable.
  - ③ Swipe the card issued on ZL500. The lock will beep twice with a blinking blue light. After a few seconds, it will beep twice with a blinking blue light again, indicating successful operation. If it beeps thrice with a blinking red light, it indicates a failed operation. Please try again by swiping the card.
- Note:** If the operation fails again, enable the gateway and swipe the card again.

### Step 5: Editing the lock details on the software

- ① Open **Device management** -> **Lock Management**, the lock will appear on the page automatically.
  - ② Click the lock name to edit the lock details. The customers can enter the **Lock Name** on the pop-up window and fill out the **Lock Name**, **Room Name**, and **Room Area** as required.
  - ③ Choose the lock to enable. After a few seconds, refresh the page, and the icons of both **Enable** and **Status of the lock** will change to green. Now, the lock can be used with the software smoothly.
- Note:** If the icons do not change to green, please wait for a few seconds and refresh again.



## ¿Cómo configurar la cerradura en el software **ZKBioHLMS**?

### Paso 1: Instalar ZKBioHLMS

- ① Busque "ZKBioHLMS" en el sitio web de ZKTeco <https://www.zkteco.com/en/> descargue el paquete de instalación e instálelo.
- ② Después de instalar e iniciar sesión correctamente, complete la información del hotel en la opción **Gestión de Habitaciones** del módulo Hotel, incluida la **Configuración de Información del Hotel**, **Tipo de Habitación**, **Habitación**, etc.

### Paso 2: Configurar el Gateway ZigBee SLG410

Por favor de revisar el proceso de configuración en la Guía Rápida del **SLG410**.

### Paso 3: Instalar el controlador (driver) del lector

En la página **Room View**, haga clic en **Driver Download** para instalar el controlador.

**Nota:** El sistema puede interrumpir la instalación del controlador. Ignore la advertencia y continúe con la instalación para enrolar las tarjetas. El controlador es seguro de usar.

### Paso 4: Enrolar la tarjeta de red predeterminada para conectar la cerradura y el gateway

- ① Abra la página Configuración de Información del Hotel, seleccione Tarjeta de Red Predeterminada y haga clic en Tarjeta de Red Predeterminada para enrolar.
- ② Abra Administración de Dispositivos, elija el gateway que se desea conectar y luego habilite.
- ③ Deslice la tarjeta enrolada en la cerradura ZL500. La cerradura emitirá dos pitidos con una luz azul parpadeante. Después de unos segundos, volverá a emitir dos pitidos con una luz azul parpadeante, lo que indica un funcionamiento correcto. Si emite tres pitidos con una luz roja parpadeante, indica una operación fallida. Vuelva a intentarlo deslizando de nuevo la tarjeta.

Debido a las actualizaciones periódicas de los sistemas y productos, ZKTeco no puede garantizar la coherencia exacta entre el producto real y la información escrita en este manual.



## Guía Rápida

Modelo: ZL500

Versión: 1.0

ZKTeco Industrial Park, No. 32, Industrial Road,  
Tangxia Town, Dongguan, China.

Phone : +86 769 - 82109991

Fax : +86 755 - 89602394

[www.zkteco.com](http://www.zkteco.com)

